




## RUB SR

# Real-Time Reference Signals Monitoring and Changeover Module



Functional Description and Specifications  
Supplement to the "Installation & Systems Manual RUBIDIUM SERIES"  
Version: 4.3  
December 2, 2020





# CONTENTS

A1	REVISION HISTORY	
A2	COPYRIGHT	
A3	GENERAL REMARKS	
<b>1</b>	<b>MODULE “SR”</b>	<b>7</b>
1.1	GENERAL DESCRIPTION	7
1.2	REAR PANEL AND CONNECTIONS	8
1.3	SPECIFICATIONS	10
1.4	TYPICAL APPLICATION DIAGRAMS	11
1.4.1	Basic Signal Flow with the <b>SR</b> Module	11
1.4.2	Example of a Complete Redundant System	12
1.4.3	GPI Connection to an External Alarm System	13
1.5	SOFTWARE UPDATE	14
1.6	ELECTRONIC PART EXCHANGE	15
<b>2</b>	<b>OPERATING DESCRIPTION</b>	<b>16</b>
2.1	FUNCTIONAL OVERVIEW	16
2.1.1	Basic Functions	16
2.1.2	Overview of Error Indications and Alarms in General	17
2.1.3	Overview of Error Indications at the Status Monitor	18
2.1.4	Error Reset	19
2.2	REAL-TIME REFERENCE MONITORING	20
2.2.1	The Signals	20
2.2.2	Overview of Status Information and Measurements	21
2.2.3	The Individual Errors	22
2.2.4	Consequences of Errors	24
2.3	REAL-TIME REFERENCE CHANGEOVER	26
2.4	SELF TEST	27
2.5	ALARMS	28
2.5.1	Overview and Suggestions for Installation	28
2.5.2	Alarms by GPI Outputs	29
2.5.3	Alarms by SNMP Traps	30
2.5.4	Entries in the Log File of an Ethernet Module	31
<b>3</b>	<b>STATUS MONITOR</b>	<b>32</b>
3.1	STATUS MONITOR BY THE ETHERNET MODULE	32
3.2	STATUS MONITOR BY A PC PROGRAM	33
3.3	SYSTEM STATUS	34
3.4	SIGNAL INPUT STATUS	37
3.5	STATUS OF FAN AND POWER SUPPLIES	39
<b>4</b>	<b>THE RUBIDIUM CONFIGURATION TOOLS</b>	<b>40</b>
4.1	THE RUBIDIUM CONFIGURATION PC PROGRAM	40
4.2	THE RUBIDIUM SERIES HTTP SERVER	40



4.3	“FUNCTIONS“	41
4.4	“KEYS“: KEYS AND LAMPS, LEDS AND GPIS	42
4.5	“SWITCHER“: SET-UP THE MONITORING AND CHANGEOVER	45
4.6	“LINK“: COMMUNICATION BETWEEN MODULES	47
4.7	“SYSTEM“: IDENTIFICATION, RESET, SNMP, FAN CONTROL	48



## A1 Revision History

No.	Date	Subject
0.n		Preliminary documents, changes without notice.
1.0	June 2, 2005	First released document.
1.1	August 23, 2005	Revised.
1.2	January 16, 2006	Revised.
2.0	December 12, 2006	Revised. Format of reference selectable.
2.1	November 20, 2007	10 MHz drift measurement.
2.2	August 14, 2008	Revised. "Reference Format" selection now separate for REF IN 1 and REF IN 2.
2.3		Revised. Since 8/2010 the standard hardware switches two signals additionally.
3.0	February 11, 2011	Completely revised.
4.0	May 7, 2013	Revised. Entries can be made to the log file of an Ethernet module. The TC link telegram 'Reference' can be sent.
4.1	September 3, 2019	Changed address of Plura Europe GmbH.
4.2	November 4, 2019	Fixed NMEA baud rate to 4800.
4.3	December 2, 2020	Re-formatted in new design.

Due to constant product development the features of this module are subject to change. The current functional description always refers to the current software and the current configuration tool.

You can download the latest version of the standard software from

<https://www.plurainc.com>.

Please be sure to use the latest configuration program after having done an update. You can download the latest version from the address above.



## A2 Copyright

Copyright © Plura Europe GmbH 2002-2020. All rights reserved. No part of this publication may be reproduced, translated into another language, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise without the prior written consent of Plura Europe GmbH.

Printed in Germany.

Technical changes are reserved.

All brand and product names mentioned herein are used for identification purposes only and are trademarks or registered trademarks of their respective holders.

Information in this publication replaces all previously published information. Plura Europe GmbH assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

For further information please contact your local dealer or:

Plura Europe GmbH  
Binger Weg 12  
D- 55437 Ockenheim  
Phone: +49 6725 918 006-70  
Fax: +49 6725 918 006-77  
E-Mail: [info@plurainc.com](mailto:info@plurainc.com)  
Internet: <http://www.plurainc.com>

## A3 General Remarks

This manual is a supplement to the '*Installation & Systems Manual RUBIDIUM SERIES*'. Please read the below listed chapters of the '*Installation & Systems Manual RUBIDIUM SERIES*', as these chapters are necessary for the safe and proper use of RUB modules:

- *A3 Warranty,*
- *A4 Unpacking/Shipping/Repackaging Information,*
- *A5 Safety Instructions,*
- *A6 Certifications & Compliances,*
- *Plug-In a Module,*
- *Remove a Module.*



# 1 Module “SR”

## 1.1 General Description

This module can compare and contrast the signals of two real-time references for indescribable differences. In the event of a failure, **SR** automatically switches to the other faultless source. The **SR** module is a must for all real-time reference systems where failure proof timing and synchronisation signals are required. It monitors the source signals for errors and phase differences. Status information about all sources is available at a status monitor.

A **PC** or one of the RUB Ethernet modules (**RUB IE** or **RUB PM**) is required to configure this module.


A front panel label **SR** visibly identifies RUB1 version modules. RUB3 version modules have this label at the rear plate. A serial number is located on the bottom side of the lower circuit board of each module.

The standard hardware of this module has all of the following key features:

- “Hot Swapping”, i.e. it is possible to insert or remove a module without interrupting the operation of other modules in this frame.
- Failure relay, connected to the FAIL\_A and FAIL\_B pins of the **RLC** connector at the rear of the frame.
- RS232 and TC\_link (RLC connector) interfaces to have access to the internal bus of the chassis.
- Four programmable function keys, lamps and LEDs on the front panel (RUB1 version only).
- Flash memory containing the firmware, so configuration and updates are possible via a PC connection. You can download the latest version of the program from:  
<https://www.plurainc.com>.
- Real-time reference input signals: PPS, time & date data string, double continuous wave signals (10 MHz).
- Changeover regarding the real-time reference input signals of two sources, utilizing latching relays.
- Alarm outputs indicating failures and warnings: Lamps and LEDs (RUB1 version only), GPIs, SNMP traps, and entries in the log file of an Ethernet module.



## 1.2 Rear Panel and Connections



### Pin assignments

10 MHz IN 1 2 x BNC (A, B)	10 MHz IN 2 2 x BNC (A, B)	10 MHz OUT 2 x BNC (A, B)
-------------------------------	-------------------------------	------------------------------




<b>REF IN 1</b> RJ45 jack 1: PPS_1 IN 2: RXD_1 IN 3: n.c. (until 8/2010) 6: n.c. (until 8/2010) 3: OptA_1 IN (since 8/2010) 6: OptB_1 IN (since 8/2010) 4: GND 5: VCC24G_OUT 7: GND IN 8: VCC5G_OUT	<b>REF IN 2</b> RJ45 jack 1: PPS_2 IN 2: RXD_2 IN 3: n.c. (until 8/2010) 6: n.c. (until 8/2010) 3: OptA_2 IN (since 8/2010) 6: OptB_2 IN (since 8/2010) 4: GND 5: VCC24G_OUT 7: GND IN 8: VCC5G_OUT	<b>REF OUT</b> RJ45 jack 1: PPS OUT 2: TXD OUT 3: n.c. 6: n.c. 4: GND 5: VCC24G_IN 7: GND OUT 8: VCC5G_IN
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------

<b>GPI OUT</b> RJ45 jack 1: GND 2: GPI_1 5: GPI_3 6: GPI_2 8: GPI_4 3: XCP (until 8/2010) 4: XCC (until 8/2010) 7: XCS (until 8/2010) 3: GND (since 8/2010) 4: OptB OUT (since 8/2010) 7: OptA OUT (since 8/2010)
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------





Signal descriptions

GND	Signal ground.
10 MHz IN 1 10 MHz IN 2	Continuous wave reference frequency inputs.
10 MHz OUT	Continuous wave reference frequency output, switched via relay 1 to one the 10MHz inputs. The outputs should be terminated externally.
PPS_1 IN, PPS_2 IN	Pulse per second, inputs. Time marks of the real-time references.
PPS OUT	Pulse per second output, switched via relay 2 to one PPS input.
RXD_1 IN, RXD_2 IN	Real-time reference time & date inputs, serial data strings.
TXD OUT	Reference time & date output, switched via relay 2 to one RXD input.
VCC24G_OUT	24 VDC voltage output, 200 mA reversible fused. This output voltage will be delivered from the power supply module in use (please notice the power supply specifications), or from the VCC24G_IN pin.
	Using VCC24G_OUT output please make sure not to exceed the total power rating of the power supply module.
VCC24G_IN	Hard wired with VCC24G_OUT signal.
GND IN/GND OUT	These signals are just hard wired.
VCC5G_IN/VCC5G_OUT	These signals are just hard wired.
GPI_1 ... GPI_4	Output signals, indicating failures, warnings, or status.
XCP, XCC, XCS (SR modules until 8/2010)	<p>Spare contacts at relay 2 for optional usage. Switching occurs in parallel to the 10MHz relay 1.</p> <p>XCC: Common XCP: Primary XCS: Secondary/Back-up</p> 
OptA_1 IN, OptB_1 IN OptA_2 IN, OptB_2 IN OptA OUT, OptB OUT (SR modules since 8/2010)	<p>2 x 2 inputs for optional usage. Switching to the outputs occurs in parallel to the 10MHz relay 1.</p> 



## 1.3 Specifications

### 10MHz IN

Connector	BNC (IEC169-8), 75 $\Omega$
DC range	$\pm 5$ V
Input impedance	2 k $\Omega$
Signal specifications	Frequency range: 10 MHz $\pm$ 5 %, amplitude range: 0.6 – 2.5 Vpp

### PPS IN, RXD IN

Input specification	Input "Low": -15.0 to +1.0V Input "High": +3.0 to +15.0V Frequency: 0 – 1 MHz
---------------------	-------------------------------------------------------------------------------------

### GPI\_1, GPI\_2, GPI\_3, GPI\_4

Output specification	Open Collector output of an NPN transistor. Max. power dissipation: 200 mW per output.  "High" state: External pull-up needed to a positive power source of $\leq 24$ VDC. Example: 2.2 k $\Omega$ @ 5VDC or 4.7 k $\Omega$ @ 12VDC or 12 k $\Omega$ @ 24VDC.  "Low" state: Output switched to GND. Max. collector current: 100 mA DC, fused (auto-recovery). Collector-emitter saturation voltage: @100 mA: Typ. 200 mV ( $\leq 600$ mV). @10 mA: Typ. 90 mV ( $\leq 250$ mV).  Frequency: 0 – 150 kHz.
----------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### VCC24G\_OUT

Output of the DC power supply of this module, normally = 23.8 VDC	Reversible fused. A continuous current of up to 120 mA may be applied over the whole specified operating temperature range. At an ambient temperature of e.g. 22 $^{\circ}$ C the output switches to a high-resistance state after a few seconds if a current of 400 mA is applied.
-------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### XCP, XCC, XCS and OptA\_1 IN, OptB\_1 IN, OptA\_2 IN, OptB\_2 IN, OptA OUT, OptB OUT

Spare contacts of the latching relay 2	Max switching power: 24 W Max switching voltage: 48 V	Max switching current: 1 A Max transportable current: 1 A
----------------------------------------	----------------------------------------------------------	--------------------------------------------------------------


### Others

Operating voltage	12 – 30 VDC
Power consumption	1.2 W at maximum
Weight	$\approx 0.4$ kg
Dimensions	Standard circuit board (W x D): 100 x 160 mm/3.94 x 6.30 inch Rear panel: RUB1: 103 x 44 mm / 4.06 x 1.73 inch RUB3: 8HP, 3RU
Environmental characteristics, operating	Temperature: +5 $^{\circ}$ C to +40 $^{\circ}$ C Relative humidity: 30 % to 85 %, non-condensing
Environmental characteristics, non-operating	Temperature: -10 $^{\circ}$ C to +60 $^{\circ}$ C Relative humidity: 5 % to 95 %, non-condensing



## 1.4 Typical Application Diagrams


### 1.4.1 Basic Signal Flow with the SR Module




- Continuous wave (10 MHz): Monitoring and changeover.
- Real time reference signals (PPS and serial time & date data string): Monitoring and changeover.



### 1.4.2 Example of a Complete Redundant System



### 1.4.3 GPI Connection to an External Alarm System



GPI alarms, default configuration:

GPI	Switcher "SR"	Switcher "SL"	Switcher "SV"
Signal 1 Failure	PPS/serial input 1 failure	LTC input 1 failure	Video/VITC input 1 failure
Signal 1 Warning	PPS/serial input 1 warning	LTC input 1 warning	Video/VITC input 1 warning
Signal 2 Failure	PPS/serial input 2 failure	LTC input 2 failure	Video/VITC input 2 failure
Signal 2 Warning	PPS/serial input 2 warning	LTC input 2 warning	Video/VITC input 2 warning

Please also notice the document 'Alarm GPO'. You may open this document at <https://www.plurainc.com>



## 1.5 Software Update

Software updates require a (windows operating system) computer and the "RUBIDIUM CONFIGURATION" program. You can download the latest version of the program from:

<https://www.plurainc.com>.

Please check the **PC** connector at your RUBIDIUM housing: There is an USB or RS232 (with a DSUB9 connector) interface installed. You now need the same interface at your computer.

The new firmware should already be stored as a **.tcf** file at your computer.

Please now execute the following steps:

1. Connect your computer to the **PC** connector of that RUBIDIUM frame where the module has been plugged.

In case of an RS232 interface: Use a straight (1:1) connection between the **PC** connector at the RUBIDIUM frame and the RS232 of the computer.

In case of an USB interface: Use a USB A-B cable between your computer and the RUBIDIUM frame.

Switch on the power of all units.

2. Execute "Rubidium Config.exe" on your computer. Select the "Port" according to the interface (USB, RS232) you are using.
3. Select the module (unit 1, 2, 3 ...).
4. Select "Flash Update" in the File menu.
5. Open the **.tcf**-file. Standard name: "Rubidium SR version.tcf".  
"version" stands for a revision no., e.g. 2.13.8.  
Click the OK button, update starts. Click the OK button at the end.
6. Update is finished now. We recommend checking module's configuration utilizing the "RUBIDIUM CONFIGURATION" program.

*During the flash update the operation of the module stops!*


*The changeover relay remains in its last position, so the signal flow of the connected signals will not be affected.*



## 1.6 Electronic Part Exchange

The hardware of the module comprises three printed circuit boards: The main electronic board at the bottom layer, the keyboard which is fixed to the main electronic board by soldered pins, and the rear panel board which is attached to the main electronic board by screws.

The rear panel board with its connectors and the latching relay consists of “mechanical” parts, so there is a good chance that a damage of the module concerns the electronic part only. The following exchange procedure removes the main electronic board and the keyboard without interrupting the signal output. No cable should be disconnected.



1. Arrangement:  
Contact your local dealer or Plura to order the main electronic board and the keyboard for a replacement. It is essential that you have as much information ready as possible: Serial number of the module, software version number, set-up and configuration. This will help to ensure that you are getting a direct replacement, even regarding the set-up values – which are stored in a non-volatile memory located at the main electronic board.
2. Preparation:  
Have a screwdriver for recessed-head screws ready.
3. Removal:  
Do not switch off the power. Do not disconnect cables. Follow the procedure described in the chapter 'Remove a Module' of the 'Installation & Systems Manual RUBIDIUM SERIES' to pull the module out of the slot. Observe precautions for handling electrostatic-sensitive devices.
4. Dismantle:  
Unscrew only the three screws as shown in the figure above: One screw at the rear plate and two screws at the rear panel board. Release the levers of the IDC connector and pull out the 20-way ribbon cable. Now the main electronic board and the keyboard can completely be removed.
5. Reassemble:  
In principle follow the procedure in the reverse order.




## 2 Operating Description

### 2.1 Functional Overview

#### 2.1.1 Basic Functions

- Monitoring the continuous wave (10 MHz) inputs; changeover in an event of a failure.
- Monitoring the reference signals (PPS, serial data); changeover in an event of a failure.
- Measurement and monitoring the drift between the continuous wave signals.
- Measurement and monitoring the time difference and drift between the reference signals.



The Status Monitor indicates:

Continuous wave (10 MHz) status information:

- Continuous wave failure: Amplitude or frequency out of range.
- Drift between input 1 and input 2.
- Error counters and error indications in case of failures and warnings.

Status information regarding the PPS and serial data string:

- Time, date and status.
- Time difference between the real-time reference signals.
- Error counters and error indications in case of failures and warnings.

Additional system status information:

- Monitor for manual and automatic changeover events.
- Error counters/error indications: Check of set-up parameters, relay monitoring.
- And more ...

PC programs are available for free: Configuration of the module = **RubidiumConfig.exe**, status monitor = **RubStatSE.exe**.

The RUBIDIUM SERIES HTTP server, located in the Ethernet module (**RUB IE** or **RUB PM**) enables the configuration of the module and offers a status monitor as well.





## 2.1.2 Overview of Error Indications and Alarms in General

This module detects errors on signals of the real-time references, or on the module itself after a self-test.

Basically, each individual error will be represented by a status, an error counter, and an indication of a failure. The indication of a failure can be disabled. If not disabled, special alarms can be raised in case of an error. This gives the user the possibility to select individual errors for an alarm indication.

Furthermore, two overall counters are giving a quick overview:


- The “**overall errors**” counter shows the sum of all individual errors. A count value of  $> 0$  indicates that at least one error has been detected.
- The “**overall failures**” counter shows the sum of all individual failures, i.e. all those errors with the failure indication not disabled. A count value of  $> 0$  indicates that at least one failure has been detected.

You can see all the individual errors and both overall counters at the [status monitor](#). Please open the status monitor to investigate the source of an error.

- Chapter ‘*Overview of Error Indications at the Status Monitor*’.
- Chapter ‘*Status Monitor*’.

RUB1 modules, i.e. modules plugged to a 1 RU chassis, indicate errors by the [ERROR LED](#) and failures by the [FAIL lamp](#) (in the default configuration):

- The LED in the “Switcher Error” function lights up as long as the “**overall errors**” counter has a count value  $> 0$ .
- The lamp/key in the “Fail” function lights up as long as the “**overall failures**” counter has a count value  $> 0$ .



GPI outputs can indicate failures and warnings:

- Chapter ‘*Alarms by GPI Outputs*’.

SNMP Traps can indicate failures and warnings.

- Chapter ‘*Alarms by SNMP Traps*’.

Entries in the log file of an Ethernet module can indicate failures and warnings.

- Chapter ‘*Entries in the Log File of an Ethernet Module*’.



### 2.1.3 Overview of Error Indications at the Status Monitor

The **System** page of the status monitor shows the “overall failures” counter, the “overall errors” counter, and the individual errors of the system:

System Status				
output	primary			
serial signals received	yes			
pps signals received	yes			
cont wave signals received	yes			
overall failures	0			
overall errors	0			
time difference	+ 00 : 00 : 00	0,0 ms	valid	
max difference	00 : 00 : 00	0,0 ms		
cont wave A drift	0	max	1	
cont wave B drift	0	max	1	
<b>changeover events:</b>				
automatic	0			
manual	1	reference 1	10.12.2010 10:04:16	
last event	manual	reference 2	10.12.2010 10:04:16	
	<b>status</b>	<b>counts</b>	<b>fail</b>	<b>disabled</b>
power on	0		0	0
relay 1	0	0	0	0
relay 2	0	0	0	0
time difference	0	0	0	0

The **Input 1** page shows the individual errors of signals at REF IN 1 and 10 MHz IN 1.

The **Input 2** page shows the individual errors of signals at REF IN 2 and 10 MHz IN 2.

Please refer to the following chapters for a detailed description of the individual errors:

→ Chapter ‘Real-Time Reference Monitoring’.

→ Chapter ‘Self-Test’.

Basically, the following happens in case of an error:

- status** Indicates the error status at this very moment: Error yes (1) or no (0). The status resets to 0 if this individual error has disappeared.
- counts** Counter counts up with every new error. Maximum count = 65,535. A count value > 0 indicates that there has been an error even if the status currently indicates no error. Simultaneously, the “overall errors” counter counts up.
- fail** Indicates the individual failure status at this very moment: Failure yes (1) or no (0). The failure indication can be disabled. The failure indication corresponds to the error status if ‘fail’ has been enabled. A failure can raise special alarms. Simultaneously, the “overall failures” counter counts up.
- disabled** The failure indication of this individual error can be disabled. If disabled, no failure will be indicated, and no special alarm will be given in case of an error.



### 2.1.4 Error Reset

The following error indications are self resettable (reset, if no errors are present):

- The individual **status bits at the status monitor**.
- The GPI outputs of functions **Signal 1 Failure, Signal 2 Failure, Signal 1 Warning, Signal 2 Warning**.

The following error indications remain as long as the overall counters have count values > 0:

„overall errors“ > 0	„overall failures“ > 0
<ul style="list-style-type: none"> <li>• LED (ERROR) in the <b>Switcher Error</b> function.</li> <li>• GPI output in the <b>System Error</b> function.</li> <li>• SNMP trap <b>System Error</b>.</li> </ul>	<ul style="list-style-type: none"> <li>• Lamp (FAIL) in the <b>Fail</b> function.</li> <li>• GPI output in the <b>System Failure</b> function.</li> <li>• SNMP trap <b>System Failure</b>.</li> </ul>

A reset of these counters and – at the same time – a reset of all individual error counters can be done by:

#### Keystroke

RUB1 modules, i.e. modules plugged to a 1 RU chassis, offer four programmable keys. The following functions are provided for a reset:

Function	Description	Recommended Key
Clear	Resets all error counters to zero.	F1: FAIL
Reset All	Complete reset of error counters and status.	F1: FAIL

It is recommended to assign the „Reset All“ function to the FAIL key.

#### Configuration

Utilizing one of the configuration tools, a complete reset of error counters and status can be done clicking the “Error Reset“ button at the **Switcher** page.



## 2.2 Real-Time Reference Monitoring

### 2.2.1 The Signals

PPS IN: "Pulse Per Second" input, electrical - for example - a TTL pulse (see chapter 'Specifications'). Positive edge = Time reference mark.


RXD IN: Serial data string, electrical - for example - RS232 (see chapter 'Specifications'). The serial data string has to be synchronized to the PPS. Normally, the data string immediately follows the PPS signal. The time and date then correspond to the leading edge of the preceding PPS.

The data protocol can be selected independently for each input utilizing one of the configuration tools: "Ref. Format Signal 1" and "ref. Format Signal 2" on the "Switcher" page. For example, the following GPS units require the following protocols:


GPS 10 MHz  
GPS16, GPS17, GPS35

Meinberg Std 2400/7e2 + PPS  
NMEA \$GPRMC 4800/8n1 + PPS

Example: PPS IN (yellow) and RXD IN (blue):



Example: 2 x 10 MHz



10 MHz IN: Sinusoidal continuous wave signals with frequency = 10 MHz.

**SR** monitors 2 x 2 of these signals. GPS or DCF77 receiver units normally output these signals. The oscillator within these units can be disciplined according to the antenna signals, thus compensating the oscillator's aging and delivering a highly accurate frequency. External devices can take this signal as a frequency reference (for example video sync generators).



## 2.2.2 Overview of Status Information and Measurements

This module monitors the signals of two real-time references. After the power has turned on, the monitoring starts if once a valid signal has been received.

<b>serial signals received</b>	yes
<b>pps signals received</b>	yes
<b>cont wave signals received</b>	yes

The time difference and drift between the real-time reference signals will be measured. The result will be shown at the **System** page of the status monitor:

<b>time difference</b>	+ 00 : 00 : 00	0,0 ms	valid
<b>max difference</b>	00 : 00 : 00	0,0 ms	
<b>cont wave A drift</b>	0	<b>max</b>	1
<b>cont wave B drift</b>	0	<b>max</b>	1

**time difference** Time difference, HH:MM:SS and milliseconds ( $\pm 0.1$  ms).  
A “+” sign means: *REF IN 1* time is equal or ahead of *REF IN 2* time. A “valid”/“invalid” flag indicates whether the current difference is valid or not. If one input fails, the time difference is invalid.  
A “time difference” error will be indicated if the time difference equals or exceeds the limit “Limit Time Diff”. This limit is programmable. Please refer to chapter ‘*The Individual Errors*’ for more information.

**max difference** Maximum value of “time difference”, HH:MM:SS, no sign.

**cont wave A/B drift** Drift between signals at *10 MHz IN 1* and *10 MHz IN 2*. Measured value shows the number of periods (10 MHz clock cycles).

Further monitoring is done separately for signals at *REF IN 1* and *10 MHz IN 1* (results at status monitor **Input 1** page) and for signals at *REF IN 2* and *10 MHz IN 2* (results at status monitor **Input 2** page).

The decoded data of the serial data string: Time, date and status information:

<b>time</b>	11 : 19 : 24	<b>sync after reset</b>	yes
<b>date</b>	06.01.2011	<b>locked</b>	yes
<b>last lock at</b>	06.01.2011 11:19:24		
<b>time since last lock</b>	0 min		
<b>max time since last lock</b>	0 min		

Errors and failures (see chapter ‘*The Individual Errors*’ for details):

	status	counts	fail	disabled
<b>changeover &amp; monitoring</b>				
<b>pps/serial timeout</b>	0	0	0	0
<b>sync loss fail</b>	0	0	0	0
<b>cont wave A</b>	0	0	0	0
<b>cont wave B</b>	0	0	0	0
<b>monitoring</b>				
<b>PPS timeout</b>	0	0	0	1
<b>PPS timing</b>	0	0	0	1
<b>serial timing</b>	0	0	0	1
<b>serial sequence</b>	0	0	0	1
<b>sync loss error</b>	0	0	0	0



### 2.2.3 The Individual Errors

The following error may occur comparing both signals at *REF IN 1* and *REF IN 2*. This error will be indicated at the **System** page of the status monitor:

Time difference between the *REF IN* signals: **Time Difference**

The module decodes the time information of the serial data string and measures the phase of the PPS. From that, the precise time difference can be calculated and displayed: “[time difference](#)” and “[max difference](#)”.

It is common practice that the time zone of both the real-time references is the same. But **SR** can handle two different time zones, e.g. one reference may have been set up to UTC, the other reference to a local time zone. This results in a time difference of hours and maybe even minutes. This time difference should not be treated as an error. Accordingly, the “Reference Compare” parameter (please refer to chapter “*Switcher: Set-up the Monitoring and Changeover*”) should receive an appropriate set-up:

HH:MM:SS	= Time difference calculated without restrictions.
MM:SS	= Comparing only minutes and seconds.
M:SS	= Comparing only unit of minutes and seconds.
SS	= Comparing only seconds.

A “[time difference](#)” error will be indicated if the time difference equals or exceeds the limit “Limit Time Diff”. This limit is programmable in the range from 1 s to 9 s.

This is the only error which is assigned together to both signal inputs. A “System Error” or “System Failure” alarm can be raised, but no warning or failure indicating a problem of a specific signal input. Therefore, this error will not be considered for a changeover.

Further monitoring is done separately for signals at *REF IN 1/10 MHz IN 1* (results at status monitor **Input 1** page) and for signals at *REF IN 2/10 MHz IN 2* (results at status monitor **Input 2** page).

Signal loss at *REF IN*: **PPS/Serial Timeout**

No valid signals detected since 20 s leads to a “[pps/serial timeout](#)” error.

This error will be classified as a major error, so this error will be considered for a changeover.

Signal loss at *10 MHz IN*: **Cont Wave A** and **Cont Wave B**

The frequency and/or amplitude of the signal at *10 MHz IN A* or *10 MHz IN B*, respectively, does not comply with the specifications (frequency range: 10 MHz  $\pm$  5%, amplitude range: 0.6 – 2.5 Vpp). This leads to a “[cont wave A](#)” or “[cont wave B](#)” error, respectively.

This error will be classified as a major error, so this error will be considered for a changeover.



**PPS loss: PPS Timeout**

No valid PPS signal detected since 10 s leads to a “pps timeout” error.

This error will be classified as a minor error, so this error will not be considered for a changeover.

**PPS disturbances: PPS Timing**

The interval between two consecutive PPS signals does not correspond to one second. This leads to a “pps timing” error.

This error will be classified as a minor error, so this error will not be considered for a changeover.

**Timing of the serial data string: Serial Timing**

If the serial data string is not synchronized with the PPS signal, a “serial timing” error will be indicated.

This error will be classified as a minor error, so this error will not be considered for a changeover.

**Continuity of the time: Serial Sequence**

A time discontinuity has been detected while checking the time & date information of the serial data string. This leads to a “serial sequence” error - even at a valid time discontinuity in case of a leap second or a DST switching of a local time zone.

This error will be classified as a minor error, so this error will not be considered for a changeover.

**Receiver indicates “unlock”: Sync Loss Error and Sync Loss Fail**

A “lock/unlock” status is given within the serial data string. “locked = yes” means that the (GPS or DCF77) receiver currently is able to synchronize to the antenna signals. **SR** monitors the duration of an “unlock” state, indicated as “locked = no”.

A “sync loss error” error will be indicated if this duration equals or exceeds the limit “Limit Sync Loss Error”. This limit is programmable in the range from 1 to 23 hours. This error will be classified as a minor error; it is intended to give a warning.

A “sync loss fail” error will be indicated if this duration equals or exceeds the limit “Limit Sync Loss Fail”. This limit is programmable in the range from 24 to 99 hours. This error will be classified as a major error, so this error will be considered for a changeover.



### 2.2.4 Consequences of Errors

The “time difference” error will be indicated at the **System** page of the status monitor:

	status	counts	fail	disabled
power on	0		0	0
relay 1	0	0	0	0
relay 2	0	0	0	0
time difference	0	0	0	0

All other errors will be indicated at the **Input 1** and **Input 2** pages:

	status	counts	fail	disabled
changeover & monitoring				
pps/serial timeout	0	0	0	0
sync loss fail	0	0	0	0
cont wave A	0	0	0	0
cont wave B	0	0	0	0
monitoring				
PPS timeout	0	0	0	1
PPS timing	0	0	0	1
serial timing	0	0	0	1
serial sequence	0	0	0	1
sync loss error	0	0	0	0

Chapter ‘Overview of Error Indications at the Status Monitor’ describes the meaning of **status**, **counts**, **fail**, and **disabled**.

Each error has the following consequences:

- Indication of an error at the status monitor (*'status' = 1*).
- Error counter counts one up.
- Counter ‘overall errors’ counts one up.
- LED programmed as ‘Switcher Error’ lights up (RUB1 version modules).
- GPI output programmed as ‘System Error’ becomes active.
- SNMP trap ‘System Error’ will be sent.

Each error has additional the following consequences if the corresponding ‘disable’ checkbox has not been checked:

- Indication of a failure at the status monitor (*'fail' = 1*).
- Counter ‘overall failures’ counts one up.
- Lamp programmed as ‘Fail’ lights up (RUB1 version modules).
- GPI output programmed as ‘System Failure’ becomes active.
- SNMP trap ‘System Failure’ will be sent.
- The log file of an Ethernet module receives an entry.

- Chapter ‘Alarms by GPI Outputs’.
- Chapter ‘Alarms by SNMP Traps’.
- Chapter ‘Entries in the Log File of an Ethernet Module’.

The individual errors separately detected for signals at REF IN 1/2 and 10 MHz IN 1/2 are divided into major and minor errors. Any major error can force a changeover. All these individual errors can raise special alarms if the corresponding ‘disable’ checkbox has not been checked:

- Major errors: “pps/serial timeout”, “sync loss fail”, “cont wave A”, “cont wave B”.
- GPI output, programmed as “Signal 1 Failure” or “Signal 2 Failure” resp.
  - SNMP Trap “Signal 1 Failure” or “Signal 2 Failure” resp.

- Minor errors: “pps timeout”, “pps timing”, “serial timing”, “serial sequence”, “sync loss error”.
- GPI output, programmed as “Signal 1 Warning” or “Signal 2 Warning” resp.
  - SNMP Trap “Signal 1 Warning” or “Signal 2 Warning” resp.





This table shows all the individual errors and their consequences:

		Individual Errors									
		Major Errors					Minor Errors				
		time difference	pps/serial timeout	sync loss fail	cont wave A	cont wave B	pps timeout	pps timing	serial timing	serial sequence	sync loss error
Status Monitor	<b>status</b> Sets bit to 1	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	<b>counts</b> Counts + 1	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	<b>overall errors</b> Counts + 1	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	<b>fail</b> Sets bit to 1	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*
	<b>overall failures</b> Counts + 1	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*
LED and Lamp	LED function <b>Switcher Error</b> LED (ERROR) lights up	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	Lamp function <b>Fail</b> Lamp (FAIL) lights up	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*
GPI Functions	<b>Signal 1 Failure</b> (GPI_1) <b>Signal 2 Failure</b> (GPI_2)	no	yes*	yes*	yes*	yes*	no	no	no	no	no
	<b>Signal 1 Warning</b> (GPI_3) <b>Signal 2 Warning</b> (GPI_4)	no	no	no	no	no	yes*	yes*	yes*	yes*	yes*
	<b>System Error</b> (if "overall errors" > 0)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	<b>System Failure</b> (if "overall failures" > 0)	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*
SNMP Traps	<b>System Error</b> (if "overall errors" > 0)	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes
	<b>System Failure</b> (if "overall failures" > 0)	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*
	<b>Signal 1 Failure</b> <b>Signal 2 Failure</b>	no	yes*	yes*	yes*	yes*	no	no	no	no	no
	<b>Signal 1 Warning</b> <b>Signal 2 Warning</b>	no	no	no	no	no	yes*	yes*	yes*	yes*	yes*
Log	<b>Event SR</b>	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*	yes*

yes\*: "yes" under the condition that the corresponding "disable" checkbox has not been checked, i.e. the status monitor shows "disabled" = 0.




## 2.3 Real-Time Reference Changeover

**SR** monitors real-time reference signals of two sources.

With the default set-up ('Factory Settings'), the module operates in the **automatic mode**, i.e. in case of any major fault of the active source a changeover will occur to the other source.

**Latching relays** are used to switch the source signals, so the signal path does not change if the module loses power.



Utilizing one of the configuration tools, you can choose an **automatic** or **manual** changeover operating mode: 'Changeover = Automatic' or 'Changeover = Manual' (please refer to chapter 'Switcher': Set-Up the Monitoring and Changeover).

RUB1 modules offer keys which enable to do a manual changeover at either operating mode. Two functions are provided (please refer to chapter 'Keys': Keys and Lamps, LEDs and GPI):

- 'Changeover to Primary': Changeover to the primary source. This is the recommended function, because it avoids any unintentional changeover to the back-up source.
- 'Changeover Toggle': Changeover between primary ↔ back-up.

Difference between *automatic* and *manual* operating mode:

	<b>Automatic</b>	<b>Manual</b>
Automatic changeover	Enabled	Disabled
Function of a key: 'Changeover Toggle' or 'Changeover to Primary'	Failure and error status checked before a manual changeover: Changeover only, if the currently inactive source has not more failures than the currently active source.	Changeover forced by a keystroke occurs regardless of any errors or failures.

In the automatic mode, the module tries to output a "good" signal while avoiding any unnecessary changeover. This leads to a sophisticated changeover characteristic. All the major errors will be considered. In brief, a changeover to the back-up signal occurs if the primary source

- has major errors and the back-up not,
- has a 'pps/serial timeout' or 'cont wave A' or 'cont wave B' error and the back-up not,
- has no 10 MHz signal and the back-up at least one.

Changeover from the back-up to the primary source works in the same way.

The changeover characteristic can be modified by setting the 'disabled' bit for individual major errors. An error which is not enabled to become a failure will be ignored for the changeover. This allows you to adapt the changeover characteristic to your application.



## 2.4 Self Test

Apart from checking the signals of the real-time references, the module performs a self test. The following errors will be indicated at the **System** page of the status monitor:

	status	counts	fail	disabled
power on	0		0	0
relay 1	0	0	0	0
relay 2	0	0	0	0

Chapter ‘Overview of Error Indications at the Status Monitor’ describes the meaning of **status**, **counts**, **fail**, and **disabled**.

‘power on’: After power has turned on, the non-volatile data will be checked for plausibility, e.g. regarding the set-up of the module. Any implausibility results in this error.

‘relay 1’, ‘relay 2’: The relays are monitored through internal sense signals. If any sense signal does not correspond to the intended switching position, it will result in an error.

Each error has the following consequences:

- Indication of an error at the status monitor (‘status’ = 1).
- In case of error ‘relay 1’ and ‘relay 2’: Error counter counts one up.
- Counter ‘overall errors’ counts one up.
- LED programmed as ‘Switcher Error’ lights up (RUB1 version modules).
- GPI output programmed as ‘System Error’ becomes active.
- SNMP trap ‘System Error’ will be sent.

Each error has additional the following consequences if the corresponding ‘disable’ checkbox has not been checked:

- Indication of a failure at the status monitor (‘fail’ = 1).
- Counter ‘overall failures’ counts one up.
- Lamp programmed as ‘Fail’ lights up (RUB1 version modules).
- GPI output programmed as ‘System Failure’ becomes active.
- SNMP trap ‘System Failure’ will be sent.
- The log file of an Ethernet module receives an entry.

→ Chapter ‘Alarms by GPI Outputs’.

→ Chapter ‘Alarms by SNMP Traps’.

→ Chapter ‘Entries in the Log File of an Ethernet Module’.

This table shows all the individual errors and their consequences:

			power on	relay 1	relay 2
Status Monitor	status	sets bit to 1	yes	yes	yes
	counts	counts + 1	no	yes	yes
	overall errors	counts + 1	yes	yes	yes
	fail	sets bit to 1	yes*	yes*	yes*
	overall failures	counts + 1	yes*	yes*	yes*
LED Lamp	LED function	Switcher Error LED (ERROR) lights up	yes	yes	yes
	Lamp function	Fail Lamp (FAIL) lights up	yes*	yes*	yes*
GPI	System Error	(if "overall errors" > 0)	yes	yes	yes
	System Failure	(if "overall failures" > 0)	yes*	yes*	yes*
SNMP	System Error	(if "overall errors" > 0)	yes	yes	yes
	System Failure	(if "overall failures" > 0)	yes*	yes*	yes*
Log	Event SR		yes*	yes*	yes*

yes\*: “yes” under the condition that the corresponding “disable” checkbox has not been checked, i.e. the status monitor shows “disabled” = 0.



## 2.5 Alarms

### 2.5.1 Overview and Suggestions for Installation

In order to get aware of a problem, the module could periodically be checked (status monitor, LEDs, lamps, log file of the Ethernet module), or the module could be integrated into a management and control system via GPI and/or SNMP.

These are the suggestions for using the GPI and SNMP features.

The usage of the **Signal 1/2 Failure** and **Signal 1/2 Warning** alarms offers the advantage that the problem directly can be related to source *REF IN 1/10 MHz IN 1* or *REF IN 2/10 MHz IN 2*. Additionally, it is possible to distinguish between failures (major errors) and warnings (minor errors). These alarms indicate real problems; none of these alarms should be raised in a real-time reference system during normal 24 hours operation. A warning indicates a situation which may lead to a major problem if no interaction will take place.

In case of a GPI connection, these advantages are given only if the GPI outputs are connected separately to inputs of an alarm management system.

The „[time difference](#)“ error as well as the errors with respect to the self test are missing if only these alarms are considered.

A complete monitoring can be realized using only one type of alarm: **System Error** or **System Failure**. Both alarms are available with firmware version 2.10.19 or higher. In case of an alarm, the cause of the alarm can be found quickly utilizing the status monitor.

**System Error:** This alarm offers monitoring with highest sensibility. Every error will raise this alarm. There is no way to disable any individual failure indication. Even the [“serial sequence”](#) error raises an alarm, for example at a valid time discontinuity in case of a leap second or a DST switching of a local time zone.

**System Failure:** Basically, this alarm combines all failures. Only those errors which are enabled to indicate a failure can raise an alarm. So, your configuration determines which of the errors with respect to the real-time references and errors with respect to the self test are considered for sending an alarm.

The **Signal 1/2 Failure** and **Signal 1/2 Warning** alarms will become inactive automatically as soon as the individual errors have disappeared. The **System Error** and **System Failure** alarms remain active until a manual reset of the error counters.

Using GPI outputs requires a proper configuration (→ chapter ‘*Alarms by GPI Outputs*’) and – of course – a proper cabling.

Using SNMP traps requires a proper configuration (→ chapter ‘*Alarms by SNMP Traps*’) and an Ethernet module (**RUB IE** or **RUB PM**) as part of this RUBIDIUM system.



## 2.5.2 Alarms by GPI Outputs

The module has four GPIs (General Purpose Interfaces). Basically, the functions of these outputs are programmable utilizing the **Keys** function of one of the configuration tools. (→ Chapter 'The Rubidium Configuration Tools' → "'Keys": Keys and Lamps, LEDs and GPIs')

The following functions for the GPIs are provided to indicate errors and failures:

**Signal 1 Failure** Recommended GPI: **GPI\_1**

**Signal 2 Failure** Recommended GPI: **GPI\_2**

Active, as long as there is a major error at *REF IN 1/10 MHz IN 1* or *REF IN 2/10 MHz IN 2* respectively. In detail, this GPI becomes active if one of the following errors has occurred and this error has been enabled to indicate a failure (checkbox "**disable**" not checked):

pps/serial timeout                      cont wave A  
sync loss fail                              cont wave B

Please refer to chapter 'Real-Time Reference Monitoring' for a detailed description.

**Signal 1 Warning** Recommended GPI: **GPI\_3**

**Signal 2 Warning** Recommended GPI: **GPI\_4**

Active, as long as there is a minor error at *REF IN 1/10 MHz IN 1* or *REF IN 2/10 MHz IN 2* respectively. In detail, this GPI becomes active if one of the following errors has occurred and this error has been enabled to indicate a failure (checkbox "**disable**" not checked):

pps timeout                                  serial timing  
pps timing                                      serial sequence  
                                                            sync loss error

Please refer to chapter 'Real-Time Reference Monitoring' for a detailed description.

**System Error** Available with firmware version 2.10.19 or higher

Active, as long as the "**overall errors**" counter has a count value > 0.

The error indication cannot be disabled, so this GPI becomes active in case of any error, i.e. errors with respect to the real-time references and errors with respect to the self test.

**System Failure** Available with firmware version 2.10.19 or higher

Active, as long as the "**overall failures**" counter has a count value > 0.

Any individual error can raise this alarm provided this error has been enabled to indicate a failure (checkbox "**disable**" not checked). Depending on this configuration, errors with respect to the real-time references and errors with respect to the self test may activate this GPI output.

More GPI functions: → Chapter "'Keys": Keys and Lamps, LEDs and GPIs'.



### 2.5.3 Alarms by SNMP Traps

SNMP functionality for a RUBIDIUM system requires the installation of an Ethernet module (**RUB IE** or **RUB PM**) with option **S** (SNMP).

Utilizing one of the configuration tools, the SNMP traps can be enabled and disabled at the **System** page (please refer to chapter *“System”: Identification, Reset, SNMP, Fan Control*). The “Any Trap” checkbox in general controls the SNMP traps functionality. Furthermore, there are checkboxes corresponding to all the individual traps.

Recommended configuration: Check the “Any Trap” and “System Failure” checkboxes.

This chapter describes all the alarm functions for traps. The following feature is valid for all these traps: As long as the alarm condition is present, traps will be repeated in an 8 hours interval.

#### **Signal 1 Failure / Signal 2 Failure** Check the “Signal Failure” checkbox

Trap will be sent, as long as there is a major error at *REF IN 1/10 MHz IN 1* or *REF IN 2/10 MHz IN 2* respectively. In detail, this trap will be sent if one of the following errors has occurred and this error has been enabled to indicate a failure (checkbox “**disable**” not checked):

- pps/serial timeout
- cont wave A
- sync loss fail
- cont wave B

Please refer to chapter *‘Real-Time Reference Monitoring’* for a detailed description.

#### **Signal 1 Warning / Signal 2 Warning** Check the “Signal Warning” checkbox

Trap will be sent, as long as there is a minor error at *REF IN 1/10 MHz IN 1* or *REF IN 2/10 MHz IN 2* respectively. In detail, this trap will be sent if one of the following errors has occurred and this error has been enabled to indicate a failure (checkbox “**disable**” not checked):

- pps timeout
- serial timing
- pps timing
- serial sequence
- sync loss error

Please refer to chapter *‘Real-Time Reference Monitoring’* for a detailed description.

#### **System Error** Check the “System Error” checkbox

Active, as long as the “**overall errors**” counter has a count value > 0.  
The error indication cannot be disabled, so this trap will be sent in case of any error, i.e. errors with respect to the real-time references and errors with respect to the self test.

#### **System Failure** Check the “System Failure” checkbox

Active, as long as the “**overall failures**” counter has a count value > 0.  
Any individual error can raise this alarm provided this error has been enabled to indicate a failure (checkbox “**disable**” not checked). Depending on this configuration, errors with respect to the real-time references and errors with respect to the self test may activate this trap.



## 2.5.4 Entries in the Log File of an Ethernet Module

The use of the log file requires the installation of an Ethernet module (**RUB IE** or **RUB PM**).

As it is shown in the tables of chapters:

- 'Real-Time Reference Monitoring' – 'Consequences of Errors',
- 'Self Test',

every error can produce an entry in the log file if the corresponding '**disable**' checkbox has not been checked.

Additional entries can be produced triggered by the following events:

- manual or automatic changeover,
- error reset – pressing key FAIL (or any key assigned with the '**Reset All**' function) or clicking the '**Error Reset**' button at the **Switcher** page of any configuration tool.

Open the log file clicking on **/public/system.log** at the **System** page of an Ethernet module.

Example: (SR 2:1) identifies the module which sent this entry:  
**SR** module located at frame address **2** at slot **1**.

```
[22/Apr/2013 14:36:14] (SR 2:1) Event: REF IN2 10 MHz B signal loss
[22/Apr/2013 14:36:14] (SR 2:1) Event: REF IN1 10 MHz A signal loss
[22/Apr/2013 14:36:14] (SR 2:1) Event: REF IN1 10 MHz B signal loss
[22/Apr/2013 14:36:14] (SR 2:1) Event: System automatic changeover
[22/Apr/2013 14:36:20] (SR 2:1) Event: REF IN2 10 MHz A signal loss
[22/Apr/2013 14:36:22] (SR 2:1) Event: System automatic changeover
[22/Apr/2013 14:36:24] (SR 2:1) Event: System error reset
```

The Ethernet module adds a time stamp (time & date) = time of its internal clock when it receives the entry.

If **SR** receives real-time reference signals and no other module of the system sends the 'Reference' telegram, this telegram should be sent from **SR** module (see chapter "'Link': Communication between Modules'). This telegram sets and synchronizes the internal clock of the Ethernet module. The time stamps of each entry now correspond to the UTC time & date of the event.



## 3 Status Monitor

### 3.1 Status Monitor by the Ethernet Module

The RUBIDIUM SERIES HTTP server, which is located in the Ethernet module (**RUB IE** or **RUB PM**), offers a status monitor.

Please refer to the '*Functional Descriptions and Specifications RUB Ethernet*' manual for a detailed description of how to access the RUBIDIUM SERIES system and how to open the RUBIDIUM homepage.

The screenshot shows the 'Configuration' page of the RUBIDIUM SERIES interface. On the left is a dark blue sidebar with the following menu items: 'Rubidium Series', 'RUB IE', 'Frame' (with a dropdown menu set to 'Single'), 'IE RUB IE', 'GT', and 'SR' (highlighted in yellow). The main content area has a top navigation bar with 'Configuration' and the 'plura' logo. Below this is a 'Status Monitor' button and a 'Not logged in Logout' link. A dark blue bar labeled 'SR' is visible, followed by a menu with 'Functions', 'Profile', 'System', 'Keys', and 'Switcher'. Below that is a grey bar labeled 'OK' and a message: 'Use the menu above to navigate through configuration settings.'

- Click on **SR** on the left
- Click on the button **Status Monitor** to open the **SR** status monitor.

#### Requirements:

- Please have Java Runtime Environment 1.6.0 or higher installed (for example download at [www.java.com](http://www.java.com)).
- Java should be installed as a browser plug-in (a Windows installation will do this automatically if you download Java from the source mentioned above).
- The Status Monitor works with all operating systems which support Java.






## 3.2 Status Monitor by a PC Program



The PC program **RubStatSE.exe** uses the **PC** interface (RS232 or USB) of the RUBIDIUM housing. This program is part of the “Rubidium Series, config software” packet you can download at:

<http://www.plurainc.com>.

Execute this program, select the COM port or USB connection and press the **scan** button to get a list of the modules plugged to this housing. Select the module and press the **connect** button.



### Requirements:

- Please have Java Runtime Environment 1.6.0 or higher installed (for example download at [www.java.com](http://www.java.com)).
- For a Windows operating system: Please follow the description of **RubStatSE\_Readme.txt**.
- For a Linux operating system: Available on request.



### 3.3 System Status

The system status and individual system error sources are considered for monitoring only, they have no effects on the automatic changeover characteristics.

**Rubidium Status Monitor SE** (Module 2: SR) | scan | disconnect | Rubidium Status Monitor 2.10.19

System | Input 1 | Input 2 | Fan Monitor

**System Tally**

relay 1	0	lamp 1	0
relay 2	0	lamp 2	1
gpi 1	0	lamp 3	1
gpi 2	0	lamp 4	1
gpi 3	0	led 1	1
gpi 4	0	led 2	1
		led 3	1
		led 4	0

**System Set-up**

changeover	automatic
limit time difference	01 s
reference time compare	HH:MM:SS
limit sync loss error	8 h
limit sync loss fail	24 h
reference format signal 1	Meinberg Standard
reference format signal 2	Meinberg Standard

**System Status**

output	primary		
serial signals received	yes		
pps signals received	yes		
cont wave signals received	yes		
overall failures	0		
overall errors	0		
time difference	+ 00 : 00 : 00	0,0 ms	valid
max difference	00 : 00 : 00	0,0 ms	
cont wave A drift	0	max	1
cont wave B drift	0	max	1
<b>changeover events:</b>			
automatic	0		
manual	1	reference 1	10.12.2010 10:04:16
last event	manual	reference 2	10.12.2010 10:04:16
<b>status</b>		<b>counts</b>	<b>fail</b> <b>disabled</b>
power on	0		0      0
relay 1	0	0	0      0
relay 2	0	0	0      0
time difference	0	0	0      0

Module version 2.10.19.0 (SR)

#### System Set-Up

Reflects the set-up as selected by a configuration tool  
(see chapter *“Switcher”: Set-Up the Monitoring and Changeover*).



System Tally

Reflects the state of the relays, the GPIs, the lamps and the LEDs. The GPIs, lamps and LEDs have programmable functions. For service purpose, 'System Tally' reflects the state of the default function, independent of what has been really assigned to.

- relay 1** Sense of the 10 MHz changeover relay: 0 = primary, 1 = back-up.  
**relay 2** Sense of the PPS/RXD/SPARE changeover relay: 0 = primary, 1 = back-up.

GPIs: 0 = output/function inactive, 1 = output/function active.

- gpi 1** 'Signal 1 Failure': Any major error at *REF IN 1/10 MHz IN 1* detected.  
**gpi 2** 'Signal 2 Failure': Any major error at *REF IN 2/10 MHz IN 2* detected.  
**gpi 3** 'Signal 1 Warning': Any minor error at *REF IN 1/10 MHz IN 1* detected.  
**gpi 4** 'Signal 2 Warning': Any minor error at *REF IN 2/10 MHz IN 2* detected.

Lamps: Lamps of the keys. 0 = off/function inactive, 1 = on/function active.

- lamp 1** 'Fail': = 1 if any failure has happened ("**overall failures**" > 0).  
**lamp 2** 'Primary': = 1 if output switched to *REF IN 1/10 MHz IN 1*.  
**lamp 3** 'Signal 1 present': = 1 if PPS and time & date at *REF IN 1* are present.  
 Toggles to indicate an imminent timeout.  
**lamp 4** 'Signal 2 present': = 1 if PPS and time & date at *REF IN 2* are present.  
 Toggles to indicate an imminent timeout.

LEDs: 0 = off/function inactive, 1 = on/function active.

- led 1** 'Operation': = 1 during normal operating.  
**led 2** 'Switcher signal': = 1 if **all** 10 MHz signals are present.  
**led 3** 'Switcher set': = 1 if PPS and RXD signals are present at *REF IN 1* **and** *REF IN 2*.  
**led 4** 'Switcher error': = 1 as long as "**overall errors**" counter > 0.

System Status

- output** *REF OUT/10 MHz OUT* currently switched to the primary or the back-up source.  
**serial signals received** Time & date monitoring and changeover procedure starts if at least one serial signal has been detected.  
**pps signals received** PPS monitoring and changeover procedure starts if at least one PPS signal has been detected.  
**cont wave signals received** 10 MHz monitoring and changeover procedure starts if at least one valid signal has been detected.  
**overall failures** Current value of the "**overall failures**" counter.  
**overall errors** Current value of the "**overall errors**" counter.  
**time difference** Current time difference between *REF IN 1* and *REF IN 2*, HH:MM:SS and milliseconds. A "+" sign means: Signal at *REF IN 1* is equal or ahead of signal at *REF IN 2*. A valid/invalid flag indicates whether the current difference is valid or not.  
**max difference** Maximum value of "tc/tc difference", HH:MM:SS and milliseconds.  
**cont wave A drift** 10 MHz drift between the signals at input *A\_IN1* and input *A\_IN2*.  
 Values 0 – 99 (current and maximum) = difference in number of periods.  
**cont wave B drift** 10 MHz drift between signals at input *B\_IN1* and input *B\_IN2*.  
 Values 0 – 99 (current and maximum) = difference in number of periods.  
 Changeover events: Number of automatic/manual changeover events. Kind and time (date & time of both real-time reference sources) of the last event.

Individual system errors:



<b>Error</b>	<b>Description</b>
<a href="#">power on</a>	Check after power has turned on: Invalid set-up parameters found and/or latching relay error found. There is no individual counter for this error.
<a href="#">relay 1</a>	Relay 1 (10 MHz changeover): Actual position not equal to intended position.
<a href="#">relay 2</a>	Relay 2 (PPS/RXD/SPARE changeover): Actual position not equal to intended position.
<a href="#">time difference</a>	The time difference between the serial data and PPS signals equals or exceeds the limit "Limit Time Diff".



### 3.4 Signal Input Status

This module monitors real-time reference signals (serial data string and PPS) at inputs *REF IN 1* and *REF IN 2* as well as continuous wave frequencies (10 MHz) at inputs *10 MHz IN 1* and *10 MHz IN 2*.

The individual errors are divided into major and minor errors:

- The **changeover & monitoring** table shows the major errors which are considered for a changeover.  
These errors can raise an alarm of type “Signal 1 Failure” or “Signal 2 Failure” respectively.
- The **monitoring** table shows the minor errors which are not considered for a changeover.  
These errors can raise an alarm of type “Signal 1 Warning” or “Signal 2 Warning” respectively.

The status monitor shows at **Input 1** and **Input 2** page:

Rubidium Status Monitor SE

AV Rubidium H1 (USB) Module 1: SR scan disconnect Rubidium Status Monitor 2.11.1

System Input 1 Input 2 Fan Monitor

Reference 1

<b>SR</b>	<b>time</b>	14 : 20 : 12	<b>sync after reset</b>	yes
	<b>date</b>	13.01.2011	<b>locked</b>	yes
	<b>last lock at</b>	13.01.2011 14:20:12		
	<b>time since last lock</b>	0 min		
	<b>max time since last lock</b>	0 min		
		<b>status</b>	<b>counts</b>	<b>fail</b> <b>disabled</b>
	<b>changeover &amp; monitoring</b>			
	<b>pps/serial timeout</b>	0	0	0      0
	<b>sync loss fail</b>	0	0	0      0
	<b>cont wave A</b>	0	0	0      0
	<b>cont wave B</b>	0	0	0      0
	<b>monitoring</b>			
	<b>pps timeout</b>	0	0	0      1
	<b>pps timing</b>	0	0	0      1
	<b>serial timing</b>	0	0	0      1
	<b>serial sequence</b>	0	0	0      1
	<b>sync loss error</b>	0	0	0      0

Module version 2.10.20.0 (SR)



**Input 1** and **Input 2** show the same items.

<b>time</b>	Current time received via serial data string.
<b>date</b>	Current date received via serial data string.
<b>sync after reset</b>	Status received via serial data string. Indicates that the reference source (GPS or DCF77 receiver) could have been synchronised to the antenna signal at least once after power-on.
<b>locked</b>	Status received via serial data string. Indicates that the reference source (GPS or DCF77 receiver) currently is synchronised to the antenna signal.
<b>last lock at</b>	Time and date of the moment when at last the "locked" status has been received.
<b>time since last lock</b>	Length of time (minutes) since status indicates "unlocked". Maximum count = 65,535 minutes (= overflow).
<b>max time elapsed</b>	Maximum value of "time since last lock".
<b>changeover &amp; monitoring</b>	
<b>Error</b>	<b>Description</b>
<b>pps/serial timeout</b>	No valid reference signals received since about 20 seconds.
<b>sync loss fail</b>	The duration of an "unlock" state equals or exceeds the limit "Limit Sync Loss Fail".
<b>cont wave A</b>	Continuous wave at input A fails: Amplitude or frequency out of range.
<b>cont wave B</b>	Continuous wave at input B fails: Amplitude or frequency out of range.
<b>monitoring</b>	
<b>Error</b>	<b>Description</b>
<b>PPS timeout</b>	No PPS signal detected since about 10 seconds.
<b>PPS timing</b>	The interval between two consecutive PPS signals does not correspond to one second.
<b>serial timing</b>	The serial data string is not synchronised with the PPS signal.
<b>serial sequence</b>	A time discontinuity has been detected while checking the serial data string. This leads to an error even at a valid time discontinuity in case of a leap second or a DST switching of a local time zone.
<b>sync loss error</b>	The duration of an "unlock" state equals or exceeds the limit "Limit Sync Loss Error".



### 3.5 Status of Fan and Power Supplies

This module – as all configurable RUBIDIUM modules – is able to monitor the fan and power supplies which are plugged to the same housing as **SR**.

The screenshot shows the 'Rubidium Status Monitor SE' application window. The interface includes a title bar, a menu bar with 'System', 'Input 1', 'Input 2', and 'Fan Monitor', and a main display area. The main display area shows a table of system parameters for 'Reference 1' and a table of monitoring parameters.

SR	time	14 : 20 : 12	sync after reset	yes	
	date	13.01.2011	locked	yes	
	last lock at	13.01.2011 14:20:12			
	time since last lock	0 min			
	max time since last lock	0 min			
	changeover & monitoring	status	counts	fail	disabled
	pps/serial timeout	0	0	0	0
	sync loss fail	0	0	0	0
	cont wave A	0	0	0	0
	cont wave B	0	0	0	0
	monitoring				
	pps timeout	0	0	0	1
	pps timing	0	0	0	1
	serial timing	0	0	0	1
	serial sequence	0	0	0	1
	sync loss error	0	0	0	0

Module version 2.10.20.0 (SR)

Please refer to the document '*Installation & Systems Manual RUBIDIUM SERIES*' for a detailed description.



## 4 The Rubidium Configuration Tools

### 4.1 The Rubidium Configuration PC Program

Please refer to the

*'Installation & Systems Manual RUBIDIUM SERIES'*

for a general description of this program and how to install it. In this document please notice the following subchapters:

- Overview
- Installation
- Connection to RUBIDIUM SERIES Chassis
- Starting the Program
- Store, Load and Update the Configuration on your PC
- The "Profile" Tab: Store and Load Configurations on the Module

The program RUBIDIUM CONFIGURATION uses various tab cards. With one click on the button **Configure**, all available and currently activated tabs of this specific module are displayed.

Any changes at a tab will immediately be stored at the module. If you enter a number or a text press the **tabulator key** at the PC's keyboard afterwards.

### 4.2 The Rubidium Series HTTP Server

The RUBIDIUM SERIES HTTP server is located in the Ethernet module (**RUB IE** or **RUB PM**). A 10/100Base-T Ethernet connection and a web browser allow access to the RUBIDIUM system.

Please refer to the *'Functional Descriptions and Specifications RUB Ethernet'* manual for a detailed description of how to access the RUBIDIUM SERIES system.

- Click on "Configuration" at the RUBIDIUM homepage to open the **Configuration** page.
- Click on the blue **SR** button to establish a communication to this module. It opens a page with a list of all the links which correspond to all the available functions.


Changes at a page will not be stored at the module automatically. At the bottom of each page there are two buttons which should be used to store or load the module's configuration:

Button **Save To Module**:

- Click on this button to transfer all settings on this page to the module.

Button **Reload From Module**:

- Click on this button to load the current configuration of the module.


	<p>Every time you click on the blue button which indicates the module under configuration, a <b>Reload</b> will be done automatically.</p>
-------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------





### 4.3 “Functions“

Click on **Functions** to see all applicable tabs/pages listed, and to activate or deactivate tabs/pages. For example (screen shot of the PC program tab):



A tab/page reflects a function of the module. The columns **Edit** and **Use** determine whether the function in the module is activated/deactivated and whether user configuration of that specific function is allowed or not.

Click on the applicable **Edit** and/or **Use** check boxes to activate/deactivate a function:

Edit	Use	
		Function is deactivated, the tab/page is not visible.
√	√	Function is activated, the tab/page is visible and configurable.
	√	Function is activated but the tab/page not visible and therefore not configurable.

- We suggest that you deactivate the **Use** check boxes of all functions you are presently not using.
- We suggest that you deactivate the **Edit** check boxes of all functions you are presently not configuring. That avoids unintentional operating and malfunctions.

List of tabs/functions:

- Profile** Store and Load Configurations on the Module (\*)
- System** Identification, Reset, SNMP, Fan Control
- Keys** Keys and Lamps, LEDs and GPIs
- Switcher** Set-Up the Monitoring and Changeover
- Link** Communication between Modules


(\*) refer to 'Installation & Systems Manual RUBIDIUM SERIES'




### 4.4 “Keys”: Keys and Lamps, LEDs and GPIs

The module has four GPIs (General Purpose Interface); the RUB1 module additionally has four illuminated buttons (keys and lamps) and four LEDs (Light Emitting Diodes). Basically, the functions of these in- and outputs are programmable.

*Some functions presented by the configuration tool maybe assigned to special options, and therefore are not applicable with the standard firmware. For further information please contact **Plura**.*



Configuration (example shows a screen shot of the PC program tab):



The following functions for the **keys** are provided for this module:

Function	Description	Recommended Key
Clear	Resets all error counters.	F1: FAIL
Reset All	Resets all error counters and status of the module.	F1: FAIL
Changeover to Primary	Manual changeover to <i>REF IN 1/10 MHz IN 1</i> ("primary" source): <u>Automatic</u> mode: Changeover occurs only if the "primary" source has not more failures than the "back-up" source. <u>Manual</u> mode: Changeover occurs without signal check.	F2: PRIMARY
Changeover Toggle	Manual changeover: <u>Automatic</u> mode: Changeover occurs only if the signal to which switching shall occur has not more failures than the current output signal. <u>Manual</u> mode: Changeover occurs without signal check	F2: PRIMARY

The following functions for the **lamps** are provided for this module:

Function	Description	Recommended Lamp
Fail	Lights up, as long as the " <b>overall failures</b> " counter has a count value > 0.	F1: FAIL
Switcher on Primary Changeover Toggle Changeover to Primary	Lights up, if the output signals are switched to the "primary" source ( <i>REF IN 1/10 MHz IN 1</i> ).	F2: PRIMARY
Signal 1 present	Lights up, if PPS and time & date at <i>REF IN 1</i> are present. Flashes to indicate an imminent timeout.	F3: REF 1
Signal 2 present	Lights up, if PPS and time & date at <i>REF IN 2</i> are present. Flashes to indicate an imminent timeout.	F4: REF 2

The following functions for the **LEDs** are provided for this module:

Function	Description	Recommended LED
OPER	Lights up, if the module is operating.	OPER
Switcher Signal	Lights up, if there are continuous wave signals (10 MHz) at all inputs.	SIGNAL
Switcher Set	Lights up, if PPS and time & date signals at <i>REF IN 1</i> <b>and</b> <i>REF IN 2</i> are present.	SET
Switcher Error	Lights up, as long as the " <b>overall errors</b> " counter has a count value > 0.	ERROR



The following functions for the **GPIs** are provided for this module:

Function	Description	Recommended GPI
Signal 1 Failure	Indicates a failure at <i>REF IN 1/10 MHz IN 1</i> .	GPI_1
Signal 2 Failure	Indicates a failure at <i>REF IN 2/10 MHz IN 2</i> .	GPI_2
Signal 1 Warning	Indicates an error at <i>REF IN 1/10 MHz IN 1</i> .	GPI_3
Signal 2 Warning	Indicates an error at <i>REF IN 2/10 MHz IN 2</i> .	GPI_4
System Error	Indicates, that the “overall errors” counter has a count value > 0.	
System Failure	Indicates, that the “overall failures” counter has a count value > 0.	
Switcher on Primary	Indicates, that the output is switched to the primary source ( <i>REF IN 1/10 MHz IN 1</i> ).	
Signal 1 present	Indicates, that PPS and time & date at <i>REF IN 1</i> are present.	
Signal 2 present	Indicates, that PPS and time & date at <i>REF IN 2</i> are present.	

Additionally, the output characteristic is selectable:

Dropdown list at <b>Mode</b>	Description
Button/Lamp	Statically, active “Low” [recommended]
Inv. Button/Lamp	Statically, active “High”
Switch/On Pulse	Pulse, active “Low”; pulse width selectable from 100 ms to 2 s. Pulse will be generated at event entry.
Inv. Switch/Off Pulse	Pulse, active “High”; pulse width selectable from 100 ms to 2 s. Pulse will be generated at the end of the event.
<b>Pulse Duration</b>	The pulse width is selectable as 100 ms, 200 ms, 500 ms, 1 s, 2 s. This selection refers to all GPO outputs set to a pulse mode.



## 4.5 “Switcher“: Set-Up the Monitoring and Changeover

These set-ups are provided for the monitoring and changeover characteristics.

Configuration (example shows a screen shot of the PC program tab):

### System Alarm Disable

**SR** monitors some system characteristics. For a detailed description of each item please refer to chapter 'Self Test' and – for "Time Diff" – to chapter 'Real-Time Reference Monitoring'. The failure indication of each individual error can be disabled by checking the "disable" checkbox. If disabled, no failure alarm will be given in case of an error.

### Reference Alarm Disable

**SR** monitors the PPS, time & date and continuous wave (10 MHz) signals of two real-time references. For a detailed description of each item see chapter 'Real-Time Reference Monitoring'.

The failure indication of each individual error can be disabled by checking the "disable" checkbox. If disabled, no failure alarm will be given in case of an error.

### Error Reset

Click this button to reset all error counters and status of the module – identical to pressing the FAIL key programmed with the "Reset All" function.



System

Select the operating mode and some parameters (default values in **bold** characters):

Item	Selection	Description
Changeover	<b>Automatic</b> Manual	Automatic or manual changeover operating mode. → Chapter 'Real-Time Reference Changeover'.
Limit Time Diff [s]	<b>1</b> – 9  Allowed range: 1 – 9 seconds	<b>SR</b> calculates and monitors the time difference between signals at REF IN 1 and REF IN 2 (PPS + RXD serial data string). A "time difference" error will be indicated if the time difference equals or exceeds this limit. → Chapter 'Real-Time Reference Monitoring' → 'The Individual Errors'.
Reference Compare	<b>HH:MM:SS</b> MM:SS M:SS SS	Special applications may utilize two reference sources which do not run within the same time zone. For example: One source at local time zone, another source at UTC. This time difference should not be treated as an error. Please select the "Reference Compare" parameter according to your application. → Chapter 'Real-Time Reference Monitoring' → 'The Individual Errors'.
Limit Sync Loss Error [h]	1 – 23 <b>(8)</b>  Allowed range: 1 – 23 hours	The RXD serial data string contains time, date and status information. The status tells about a "lock" or "unlock" of the source. <b>SR</b> calculates and monitors the duration of an "unlock" state. If the elapsed time equals or exceeds this limit, a "sync loss error" error will be indicated. The corresponding alarm indicates a warning. → Chapter 'Real-Time Reference Monitoring' → 'The Individual Errors'.
Limit Sync Loss Fail [h]	<b>24</b> – 99  Allowed range: 24 – 99 hours	The RXD serial data string contains time, date and status information. The status tells about a "lock" or "unlock" of the source. <b>SR</b> calculates and monitors the duration of an "unlock" state. If the elapsed time equals or exceeds this limit, a "sync loss fail" error will be indicated. The corresponding alarm indicates a failure. → Chapter 'Real-Time Reference Monitoring' → 'The Individual Errors'.
Reference Format Signal 1/2	<b>Meinberg Std ...</b> NMEA \$GPRMC... Meinberg Uni ... Wharton Status ...	<b>SR</b> expects a PPS and a serial data string from the real-time reference sources. The format and protocol of the serial data string should be selected in accordance with the connected device: "Meinberg Std 2400/7e2 + PPS" [GPS 10MHz, GLS 10MHz] "NMEA \$GPRMC 4800/8n1 + PPS" [GPS35, GPS16, GPS17] If "Meinberg Std 2400/7e2 + PPS" has been selected, <b>SR</b> automatically accepts the "Meinberg GPS" protocol as well. → Chapter 'Real-Time Reference Monitoring' → 'The Signals'.




## 4.6 “Link”: Communication between Modules

**Link** uses the Rubidium internal TC\_link interface to transmit or receive data. This interface is shared by all the modules in one frame, and via the **RLC** connector it is possible to link further modules at different frames.

In case that the selected module should transmit data, **Link** selects the channel and the kind of data. The receiving module must select this channel as a reader input.

In case that the selected module should receive data, the **Link** function has to be activated (**Use**), and the selected channel (“Telegram” 1 or 2 or 3) has to be switched off.

Configuration (example shows a screen shot of the PC program tab):



### Send Data

Three channels (**Telegram 1 - 3**) have been provided to transmit data.

For each channel a function can be selected from the drop-down list:

<i>Off</i>	This channel will not be used to transmit data, data can be received.
<i>Reference</i>	This channel transfers once per second time and date (UTC) of the active external reference (REF IN 1 or REF IN 2, dependent on the state of the changeover relay), as long as there are valid signals (PPS IN, RXD IN).

### Display


Adjust the parameters controlling the display of a RUBIDIUM **D1** or **Q1** chassis.

<b>Source</b>	Select the kind of data to be sent and displayed:
	<i>Off</i> No data will be sent from this module.
	<i>Reference Time</i> Time of the external reference (UTC) in a HH:MM:SS format.
	<i>Reference Date</i> Date of the external reference (UTC) in a Day.Month.Year format.
<b>Brightness</b>	Adjust the brightness of the LEDs, steps 1 to 7.
<b>Secondary</b>	Address the 'secondary' display instead of the 'primary' display.



## 4.7 “System“: Identification, Reset, SNMP, Fan Control

Configuration (example shows a screen shot of the PC program tab):



### Unit

**Name:** The connected module can get a name. You may enter, change, or verify this name at this window.

**Frame:** Modules in a network can be uniquely identified by a frame number and the module’s position within the frame. In a single frame system, you may select “Single” or “Auto” at this set-up. If a system is built-up of more than one frame, each frame has to receive a unique address (adjusted at the fan module). If you select “Auto”, the module will request this frame number automatically and will show it on the info box. Likewise, it is possible to select a frame number manually.

### Boot

**Cold Boot:** Do a cold boot of the module.

**Warm Boot:** Do a warm boot of the module.

### Info

Displays module’s status information.

### SNMP Trap Enable

Activate the “Any Trap” check box to enable the SNMP functionality in general. If not checked, this module will not send any SNMP traps.

The individual traps can be enabled/disabled by a click on the corresponding check box. Please notice the chapter ‘Alarms by SNMP Traps’ as well.

### Thermal Control

At least one module of each frame should have the fan monitoring activated. This enables the power supply monitoring – for power supplies within this frame - as well.







## Contact Us



Corporate Offices:  
Plura Broadcast, Inc.  
Ph: +1-602-944-1044  
[Sales@plurainc.com](mailto:Sales@plurainc.com)



Plura Europe GmbH  
Ph: +49-6725-918006-70  
[Sales@plurainc.com](mailto:Sales@plurainc.com)

GERMANY



Plura MEA  
Ph: +971-50-715-9625  
[Sales@plurainc.com](mailto:Sales@plurainc.com)



Plura Asia  
Ph: +82-10-6688-8826  
[Sales@plurainc.com](mailto:Sales@plurainc.com)

S. KOREA

