



# **ICAC**


## **Quick Start Guide**

**ICAC - ( Intelligent Connection for  
Alignment & Calibration )**


**Calibration Process**

# QUICK START GUIDE - CALIBRATION PROCESS


## 1. Select "Calibration" Tab




## 2. Select "Uniformity" if calibrating Uniformity



## 3. Select "Gamma" and Gamma Level




## 4. Select number of steps




# QUICK START GUIDE - CALIBRATION PROCESS


## 5. Ensure correct setting for monitor source & backlight




## 6. Select color space if calibrating PRM



## 7. Select Calibrate




## 8. Select OK will only be there for 15 sec.\*



\*After the 15 seconds it will automatically save it to the monitor.

# QUICK START GUIDE - CALIBRATION PROCESS

## 9. Notice save eeprom.





[www.plurabroadcast.com](http://www.plurabroadcast.com)

**Plura Broadcast, Inc. - West Coast**

1930 W. Quail Ave.  
Phoenix, AZ 85027  
Tel: (602) 944-1044  
Fax: (602) 324-9688

**Plura Broadcast, Inc. - East Coast**

67 Grand Avenue  
Massapequa, NY 11758  
Tel: (516) 997-5675  
Fax: (516) 593-7900