



ICAC


Quick Start Guide

**ICAC - (Intelligent Connection for
Alignment & Calibration)**


Measurement process

QUICK START GUIDE - MEASUREMENT PROCESS


1. Select "Measure" Tab.




2. Make sure Gamma, Color & Color Temperature are selected. . .



3. If measuring "Uniformity", select Uniformity




4. If measuring Color Space on PRM select...




QUICK START GUIDE - MEASUREMENT PROCESS


5. Uncheck the color space(s) you don't want to measure.




6. Select color space RGB triangle to display RGB Triangle



7. Select "Measure" . . .




8. Read measured results . . .




QUICK START GUIDE - MEASUREMENT PROCESS


9. Select "Save As" to save Measured data.




10. Select desired location and "Save" data.



11. Select "Save As" to Save log.



12. Select desired location and "Save" log





www.plurabroadcast.com

Plura Broadcast, Inc. - West Coast

1930 W. Quail Ave.
Phoenix, AZ 85027
Tel: (602) 944-1044
Fax: (602) 324-9688

Plura Broadcast, Inc. - East Coast

67 Grand Avenue
Massapequa, NY 11758
Tel: (516) 997-5675
Fax: (516) 593-7900